

Software Release Notes

dSS V1.13.6

The digitalSTROM AG uses Software Release Notes (SRN) to provide information about software changes and updates of existing products.

Document-Number	SRN-1706
Date/Version	04.07.2017 / v1.2

Important: when updating from version 1.10.3, the update dialog will not close automatically. Therefore, the Configurator must be reloaded manually latest 30 minutes after the update started.

New Features

Integration of V-ZUG Home Dishwasher

In addition to the already integrated ovens, steamers, washing machines and dryers from V-ZUG, the integration of dishwashers is supported with this version as well. This is available on the dSS20/22, dSS-IP and the dSS11-E only.

More information can be found on: <https://productinfo.digitalstrom.com/v-zug/>

Improvements

The new version provides the following improvements and bug fixes:

- The consumption event 'turn off' of a SW-KL or SW-ZWS was not sent if the terminal block itself was turned off. When saving the consumption event configuration from the configurator's Hardware tab again, the configuration will be changed and the 'turn off' event will be sent.
- The dSS20 and dSS22 could not reliably establish the Ethernet connection with some network routers.
- When configuring the inputs of a SW-UMR, some settings could not be saved or were displayed wrongly.
- The output color for DALI composite lights (connected through a P44-Bridge) could not be set from the Configurator.
- General improvements and error corrections.

Software Update Recommendation

Updating to this software-version is recommended to benefit from the latest improvements and features.

Documentation

Further information about the features and how to use them can be found in the latest digitalSTROM manual under "Operation and Configuration" or "Installation".

The latest version of the manuals can be found on:

<http://www.digitalstrom.com/en/Partner/Support/Operating-manuals/>.

Affected Products


Product	Software Description	New Version	Release date
digitalSTROM-Server - dSS11 - dSS11-E - dSS20 / dSS22 - dSS-IP	dSS Version	1.13.6	04.07.2017
digitalSTROM-Meter - dSM11 - dSM12	ARM-Software-Version DSP-Software-Version	1.32.0.0 1.8.0.0	04.07.2017

Installation Notes

- Execute the software update from the digitalSTROM configurator within the menu "*System / System Update*".
- The dSS must be connected to the Internet in order to perform the update. Alternatively, the update can be installed by using a USB thumb drive.
- It is advisable to back up your system settings prior to performing a system update within the menu "*System / System Maintenance*".
- Once the system updates are installed, the system again checks for available updates. In case there are additional dSM firmware updates available, they must be installed manually by clicking the "*Update dSM firmware*" button.
- Please note that the server-apps must be updated separately from the menu "*Apps / Update*".
- When using another digitalSTROM-Server in gateway mode, this server must be updated separately.
- A complete list of release notes as well as the USB update file can be found at <http://www.digitalstrom.com/Partner/Support/Software-Updates/>.

How to find the version information

The currently installed software version can be found within the digitalSTROM Configurator.



The screenshot shows the digitalSTROM Configurator interface. At the top, there are navigation tabs: Apps, Aktivitäten, Räume, Gruppen, System, Hardware, and Hilfe. Below this is the 'Meter' section, which contains a table with columns: Status, Name, dSM ID, Anzahl Geräte, Neue Geräte Sperren, Leistung (...), ARM Soft., DSP Soft., and HW Version. Two rows are visible, with the 'ARM Soft.' and 'DSP Soft.' columns circled in red. Below the 'Meter' section is the 'Geräte' section, which displays 'dSM-Software Version: ARM DSP'. Below this is a table with columns: Name, dSID, Ausgang, Eingangs Modus, Eingang, Raum Name, Rau..., HW Info, Firm..., Regist..., Inaktiv..., and Below the 'Geräte' section, the 'dSS Version' is displayed as '1.8.0', which is circled in red. At the bottom right of the interface, there are buttons for 'Ansicht aktualisieren', 'Standard Ansicht', and a language dropdown set to 'Deutsch'.

Status	Name	dSM ID	Anzahl Geräte	Neue Geräte Sperren	Leistung (...)	ARM Soft.	DSP Soft.	HW Version
●	F1 EG Wohnraum Küche	00000671	9	deaktiviert	2	1.16.0.0	1.4.1.0	17.1.2.16
●	F1 EG Korridor Schlafzimmer	00000713	10	aktiviert	2	1.16.0.0	1.4.1.0	11.1.21.0

Name	dSID	Ausgang	Eingangs Modus	Eingang	Raum Name	Rau...	HW Info	Firm...	Regist...	Inaktiv...	...
Deckenleuchte	0001890c	gedimmt			Schlafzimmer	2	GE-KM200	3.1.7	9 11:50:39		
Taster Schlafzim...	000064f6	deaktiviert			Schlafzimmer	2	GE-TKM210	3.1.4	9 11:48:36		
Paniktaster	00009abb	deaktiviert	Panik		Wohnraum	4	RT-TKM200	3.1.5	9 11:49:43		
Jalousie	00016c22				Schlafzimmer	2	GR-KL200	3.2.1	9 11:48:42		

1.8.0 dSS Version

Ansicht aktualisieren Standard Ansicht Deutsch

Fig. 1: Version number for dSS and dSM